


# AURA task & executive chairs

Operating instructions







Backrest locked in 5 positions




Tilt tension adjustment




Seat height adjustment



Backrest height adjustment




Depth-adjustable seat



Height adjustment at armrest carrier






Width adjustment at armrest carrier



Depth adjustment of the pad



Headrest (only for executive chairs)